

	Motor HP	Volts	Load Amps	Fuse Max Size	Circuit Breaker	Service Disconnect Amps
3 Phase	3 HP	3/208	8.43	20	20	30
		3/230	7.6	20	20	30
		3/460	3.8	10	15	30
3 Phase	5 HP	3/208	15.8	25	30	30
		3/230	14.1	25	30	30
		3/460	7.47	10	15	30
3 Phase	7.5 HP	3/208	21	30	40	30
		3/230	19	30	40	30
		3/460	10	15	20	30
	10 HP	3/208	30.8	45	70	60
		3/230	28	45	60	60
		3/460	14	25	30	30
	15 HP	3/208	40.3	60	90	60
		3/230	36.4	60	90	60
		3/460	18.2	30	40	30
	20 HP	3/208	54.6	100	125	200
		3/230	49.4	90	125	100
		3/460	24.7	45	60	60
	30 HP	3/208	88	150	175	200
		3/230	80	100	125	200
		3/460	40	60	90	60
Single Phase	3/4 HP	1/208	13.8	20	20	30
		1/230	6.9	10	15	30
	1 HP	1/120				
		1/208				
		1/230				
	3 HP	1/208	18.7	30	45	30
1/230		17	25	40	30	
5 HP	1/208	30.8	50	70	60	
	1/230	28	45	60	60	
7.5 HP	1/208	35.5				
	1/230	34				
10 HP	1/208	55	60	80	100	
	1/230	50	60	80	100	